



basin 4 m - 3 tubes of 1.80 m
 basin 5 m - 3 tubes of 2.40 m
 basin 7 m - 3 tubes of 2.80 m


List of pieces




Auto Pool Cover Roller


Installation instructions

4M and 5M and 7M




part number	qty	part number	qty
1	1	12	4
2	1	13	1
3	1	14	1
4	1	15	4
5	1	16	1
6	1	18	16
7	1	19	16
8	1	20	8
9	9	21	8
10	1	21	1
11	6	22	1
		23	1







-Fixing the cover
with screw



-Fixing the cover
with screw




-Put a nut on the inside
and another outside to
adjust the level
depending on the floor.
Use the flat key to adjust
and tighten the nuts.



- Manual Version



- 1.unplug the cable
- 2.insert the crank
- 3.put the pin to fix the
crank




- Electric version

- 1.connect the cable
- 2.insert the pin to
lock.

- Battery recharge:



- With the key
1. To the right turns clockwise
1. In the middle off
3. To the left turn counterclockwise.



- With the remote control

1. The top arrow, turns clockwise
2. The edge of the middle stop
3. The bottom arrow rotates counterclockwise.